

## E30love.com Euro Clock 'Plug & Play' Install Instructions: 6 Button OBC

Thank you for ordering the euro clock install kit. This kit allows you to install a BORG analog euro clock into your BMW E30, E24 or E28 that originally came with a 6 Button OBC.

Note:

If you have a 13 button OBC, you need to use the "13 Button" Kit & Instructions. Please confirm you have the correct kit for your vehicle. If not, please contact [info@e30love.com](mailto:info@e30love.com).

### 6 Button OBC Replacement Instructions:

The euro clock and the 6 button OBC share the same dashboard mounting configuration, so setup of your clock will be quick & easy.

- 1) Disconnect your battery. Please do not skimp on this step. It's a extra few minutes, but it will greatly reduce the possibility that anything could go wrong. An accidental electrical 'short' is the biggest concern you could have when disconnecting any equipment and this virtually eliminates that possibility. If you have an OEM stereo - make sure you have the radio code, so you can re-enable your radio once the power is restored. Google about this if you haven't experienced this radio code reset process before. For an e30 your battery will be either in your trunk on the right under a cover, or under the hood on the passenger side. Disconnect the negative lead and insulate it so it can not accidentally make contact with any metal pieces of the car.
- 2) Use a plastic pry tool, thin plastic spade, fingernails, or similar tool to pry off the OBC face. It is connected on its 4 corners with small plastic posts that insert into holes in the obc body. Fit the tool in the gap between the obc faceplate and the HVAC panel. Gently pry up. It will pop off. There are some videos on YouTube about removing 6 button OBC's if you want to see a video demonstration.



- 3) Once the face is removed, push down on the top tab, and up on the bottom tab with two plastic pry tools or your fingernails and pull slightly forward. The Unit will pop out.



- 4) Pull OBC gently towards you, flip up the black lever & remove the female wiring connector from the back of the OBC. It will have 12 female connector openings. Your adapter posts will plug into this. For the sake of this guide, the top part we'll call the 'wire side' and the other the 'bottom side'



- 5) Take a look at your supplied "Clock Adapter" cable. The white molex end has a colored dot on the top side that should face up after plugging into the clock back. Similarly, the black header connector has a dot on the top side, which should face upwards towards the "wire end" of the green female dash harness connector. The dot is on the same end as the orange or red wire. This end should point upwards towards the ceiling. This direction is important for proper clock function. Please visually confirm this alignment.
- 6) Take the black "Clock Adapter" end - line up the dot with the top/wire side of the plug and slide the 12 connectors into the female plug. It has been lubricated with "DeOxit" contact solution to help make a quality electrical handshake with the plug. Do not remove this contact solution if you can help it. Note: push in slowly and directly. Be gentle if you try to remove the plug later. The terminals make a tight seal with the clock terminals for electrical security. Pulling directly on the wires could damage the adapter.

- 7) Wrap the included zip tie around the connected plugs and tighten snugly so the two are secured together.
- 8) Cut off loose end of zip tie.
- 9) Insert white Molex end into Clock with dot facing upwards. Grip the plug by the white plastic housing, and push gently but assertively inwards until connectors slide together snugly. Stop once tight. If you look closely, you'll see the clock has 4 posts, and 1 missing position. This will line up with your connector posts.
- 10) Insert your clock gently into the OBC opening until the top and bottom tabs 'click'.
- 11) Apply the clock faceplate onto clock face.
- 12) Reconnect battery.
- 13) Start vehicle and test clock - set time with + and - buttons, test amber backlight light goes on when headlights are turned on. If your backlight does not come on, please remove clock and verify you have a 'good' lightbulb.

You're done! Enjoy your clock.

Any questions please email [info@e30love.com](mailto:info@e30love.com).

- E3L